

Code: TSS43

Name: Samsung Washing Machine Pressure Switch

Compatible with:

Samsung WA10B7Q1IW, WA10F5S5QWA, WA10G9DEP, WA10G9QIC, WA10U3WIP, WA10U7WEH, WA10UPBIP, WA10V5WEP, WA10V5WIP, WA10V9QEP, WA10V9XIP, WA10W9MIC, WA10WPBIC, WA11F5S4UWA, WA11F5S4UWA, WA11F5S4UWA, WA11F5S4UWW, WA11J5710SG, WA11WPBIC, WA12B9DEP, WA12G9DEP, WA12GPXIC, WA12V5JIC, WA12V5WEP, WA12VPYIC, WA12W9IIC, WA12W9QIC, WA12W9XIP, WA13F5S2UWW, WA13F5S2UWY, WA13F5S4UWA, WA13F5S4UWA, WA13F5S4UWW, WA13J5710SG, WA13J5730SS, WA13U7WEH, WA13U7WIP, WA13UPBIP, WA13V5WIP, WA13V9LIP, WA13V9XIP, WA14B9DEP, WA14V9WEP, WA90F5S2UWW, WA90F5S2UWW, WA90F5S5QWA, WA13SPW