

Code: D1749190100

Name: Door Cabinet Seal

Compatible with:

DEFY DAW387, DAW386, DAW384, DAW388, DWD318, DWD319, BAW388

DEFY DDW177, DDW178, DDW126, DDW130, DDW165, DDW167, DDW131, DDW141, DDW142, DDW143, DDW149, DDW140, DDW153, DDW155, DDW150, DDW151, DDW175, DDW176, DDW152, DDW156, DDW157, DDW164, DDW168, DDW179, DDW169, DDW144, DDW147, DDW148, DDW173, DDW174, DDW180, DDW181, DDW184S, DDW220, DDW230, DDW232, DDW236, DDW247, DDW354, DDW356

Beko BM8008, DEN48520GB, DFC04210W, DFN1001, DFN1500, DFN1503, DFN5610S, DFN6510, DFN6837, DFN05210S, DFN05210W, DFN05210W, DFN05310S, DFN05310W, DFN05311X, DFN05X10S, DFN05X11S, DFN15R10X, DFN15X10X, DFN16430G, DFN38B76W, DIN5630, DIN5630XN, DIN5834, DIN28320, DIN28422, DIN46520, DSN1500X

Grundig GNF11511, GNF41820, GNF41830, GNF44820, GNF54030, GNI41832, GNU41820, GNU4182